




DIAPHRAGM PUMP REPLACEMENT PARTS OVERVIEW

VERDERAIR®

Original Quality at a Better Price!

Disclaimer: Think Pump Parts BV is not affiliated with this listed company. I Think Pump Parts BV products are not authorized or manufactured by this company. Think Pump Parts BV offer non-genuine parts for this listed company.

VERDER-AIR® is a registered trademark of Verder BV

THINQK PUMP
PARTS

PART NUMBER	DESCRIPTION
T15A658	Manifold Outlet (T15A658) ALUMINIUM
T15A658	Manifold Outlet (T819.0228) ALUMINIUM
T819.0038	Repair kit (T819.0038)
T819.0060	Diaphragm (T819.0060) SANTOPRENE
T819.0061	Repair kit (T819.0061)
T819.0074	Repair kit (819.0074)
T819.0076	Repair kit (T819.0076)
T819.0089	Repair kit (T819.0089)
T819.0112	Repair kit (819.0112)
T819.0133	Repair kit (819.0133)
T819.0138	Repair kit (819.0138)
T819.0164	Stop (T819.0164) ACETAL
T819.0166	Spring (T819.0166) STAINLESS STEEL
T819.0167	Collar (T819.0167) STAINLESS STEEL
T819.0169	Bearing (T819.0169) ACETAL
T819.0172	Gasket (T819.0172) BUNA
T819.0173	Plate (T819.0173) STAINLESS STEEL
T819.0174	Saddle (T819.0174) ACETAL
T819.0175	Self-tapping pan head screw (T819.0175)
T819.0177	Spacer (T819.0177) Acetal
T819.0179	O-Ring (T819.0179) BUNA
T819.0184	Key Lube (T819.0184)
T819.0185	Hex nut (T819.0185)
T819.0187	Lock washer (T819.0187)
T819.0190	Piston (T819.0190) ACETAL
T819.0194	O-Ring (T819.0194) PTFE
T819.0196	Clamp (T819.0196)
T819.0198	Hex nut (T819.0198) STAINLESS STEEL
T819.0200	Fluid Cover (T819.0200) Polypropylene
T819.0201	Manifold BSPT (T819.0201) Polypropylene
T819.0202	Piston (T819.0202) POLYPROPYLENE
T819.0205	Seat (T819.0205) ACETAL
T819.0210	Ball (T819.0210) PTFE
T819.0211	Ball (T819.0211) STAINLESS STEEL
T819.0213	Ball (T819.0213) BUNA
T819.0214	Diaphragm (T819.0214) PTFE
T819.0217	O-Ring (T819.0217) BUNA
T819.0218	Diaphragm (T819.0218) HYTREL
T819.0219	Diaphragm (T819.0219) BUNA
T819.0220	Ground screw (T819.0220) ALUMINUM
T819.0221	Hex head flange bolt (T819.0221) SST
T819.0223	Liquid chamber (T819.0223) ALUMINUM
T819.0224	Manifold outlet (T819.0224) NPT ALUMINUM
T819.0225	Manifold outlet (T819.0225) BSPT ALU
T819.0226	Fluid Cover (T819.0226) ALU
T819.0227	Manifold Outlet NPT (T819.0227) ALU
T819.0247	Housing, center (T819.0247) SST
T819.0248	Valve plate (T819.0248) STAINLESS STEEL
T819.0249	Air Valve Kit (T819.0249)
T819.0258	Piston (T819.0258) ALUMINIUM
T819.0259	Air Valve Cover (T819.0259) SST
T819.0269	Diaphragm Kit (T819.0269)
T819.0270	Diaphragm (T819.0270) PTFE
T819.0271	Diaphragm (T819.0271) PTFE
T819.0279	Fluid Chamber (T819.0279) PP CONDUCTIVE

PART NUMBER	DESCRIPTION
T819.0282	Diaphragm (T819.0282) PTFE
T819.0283	Repair kit (T819.0283)
T819.0288	Manifold Outlet (T819.0288) PP COND.
T819.0289	O-Ring (T819.0289) VITON
T819.0317	Manifold (T819.0317) PVDF
T819.0331	Piston (T819.0331) CARBON STEEL
T819.0336	Piston (T819.0336) CARBON STEEL
T819.0426	Check ball kit (T819.0426)
T819.0433	Ball (T819.0433) SANTOPRENE
T819.0434	Muffler 3/8" (T819.0434)
T819.0451	Shaft (T819.0451) ACETAL
T819.0519	Muffler 3/4" (T819.0519) MNPT
T819.0535	Piston (T819.535) ALUMINIUM
T819.0540	O-Ring (T819.0540) EPDM
T819.0541	O-Ring (T819.0541) EPDM
T819.0542	O-Ring (T819.0542) EPDM
T819.0543	O-Ring (T819.0543) PTFE
T819.0544	O-Ring (T819.0544) PTFE
T819.0550	O-Ring (T819.0550) PTFE
T819.0609	Repair kit (T819.0609)
T819.0662	Air Valve Kit (T819.0662)
T819.0667	Air Valve Kit (T819.0667)
T819.0781	Diaphragm Kit (T819.0781)
T819.0782	Repair kit (T819.0782)
T819.0783	Repair kit (T819.0783)
T819.0784	Repair kit (T819.0784)
T819.0785	Repair kit (T819.0785)
T819.0844	Repair kit (T819.0844)
T819.0864	Repair kit (T819.0864)
T819.0868	Repair kit (T819.0868)
T819.0882	Repair kit (819.0882)
T819.0883	Repair kit (T819.0883)
T819.0884	Repair kit (T819.0884)
T819.0895	Repair kit (T819.0895)
T819.0901	Repair kit (T819.0901)
T819.0906	Repair kit (T819.0906)
T819.0909	Repair kit (T819.0909)
T819.0912	Repair kit (T819.0912)
T819.0916	Repair kit (T819.0916)
T819.0918	Repair kit (T819.0918)
T819.0923	Repair kit (T819.0923)
T819.0943	Repair kit (T819.0943)
T819.0949	Repair kit (T819.0949)
T819.0957	Repair kit (T819.0957)
T819.0984	Repair kit (T819.0984)
T819.0986	Repair kit (T819.0986)
T819.0992	Repair kit (T819.0992)
T819.1050	Repair kit (T819.1050)
T819.1053	Repair kit (T819.1053)
T819.1123	Repair kit (T819.1123)
T819.1156	Repair kit (T819.1156)
T819.1171	Repair kit (T819.1171)
T819.1277	Diaphragm kit (T819.1277)
T819.1315	Repair kit (T819.1315)
T819.1334	Manifold inlet (T819.1334) SST

PART NUMBER	DESCRIPTION
T819.1335	Manifold Outlet (T819.1335) SST
T819.1337	O-Ring (T819.1337) kit
T819.1418	Repair kit (T819.1418)
T819.1428	Repair kit (T819.1428)
T819.1433	Diaphragm Kit (T819.1433)
T819.1965	Repair kit (T819.1965)
T819.1966	Repair kit (T819.1966)
T819.1969	Diaphragm Kit (T819.1969)
T819.1970	Repair kit (T819.1970)
T819.1971	Repair kit (T819.1971)
T819.1972	Repair kit (T819.1972)
T819.2008	Repair kit (T819.2008)
T819.2009	Repair kit (T819.2009)
T819.2010	Repair kit (T819.2010)
T819.2019	Repair kit (T819.2019)
T819.2028	Repair kit (T819.2028)
T819.2031	Repair kit (T819.2031)
T819.2033	Repair kit (T819.2033)
T819.2037	Repair kit (T819.2037)
T819.2083	Repair kit (T819.2083)
T819.2085	Repair kit (T819.2085)
T819.2090	Repair kit (T819.2090)
T819.2133	Repair kit (T819.2133)
T819.2136	Repair kit (T819.2136)
T819.2177	Repair kit (T819.2177)
T819.2184	Repair kit (T819.2184)
T819.2192	Repair kit (T819.2192)
T819.2206	Repair kit (T819.2206)
T819.2219	Repair kit (T819.2219)
T819.2247	Repair kit (T819.2247)
T819.2248	Repair kit (T819.2248)
T819.2536	Repair kit (T819.2536)
T819.2539	Repair kit (T819.2539)
T819.2544	Repair kit (T819.2544)
T819.2554	Repair kit (T819.2554)
T819.2559	Repair kit (T819.2559)
T819.2589	Repair kit (T819.2589)
T819.2597	Repair kit (T819.2597)
T819.2626	Repair kit (T819.2626)
T819.2656	Repair kit (T819.2656)
T819.2674	Repair kit (T819.2674)
T819.3457	Repair kit (T819.3457)
T819.3458	Repair kit (T819.3458)
T819.3487	Repair kit (T819.3487)
T819.3491	Repair kit (T819.3491)
T819.3500	Repair kit (T819.3500)
T819.3554	Repair kit (T819.3554)
T819.3589	Repair kit (T819.3589)
T819.3591	Repair kit (T819.3591)
T819.3652	Repair kit (T819.3652)
T819.3708	Repair kit (T819.3708)
T819.3709	Repair kit (T819.3709)
T819.3710	Repair kit (T819.3710)
T819.3733	Repair kit (T819.3733)
T819.3736	Repair kit (T819.3736)

PART NUMBER	DESCRIPTION
T819.3739	Repair kit (T819.3739)
T819.3743	Repair kit (T819.3743)
T819.3751	Repair kit (T819.3751)
T819.3752	Repair kit (T819.3752)
T819.3792	Repair kit (T819.3792)
T819.3794	Repair kit (T819.3794)
T819.3795	Repair kit (T819.3795)
T819.3796	Repair kit (T819.3796)
T819.3798	Repair kit (T819.3798)
T819.3800	Repair kit (T819.3800)
T819.3801	Repair kit (T819.3801)
T819.3802	Repair kit (T819.3802)
T819.3804	Repair kit (T819.3804)
T819.3805	Repair kit (T819.3805)
T819.3807	Repair kit (T819.3807)
T819.4272	Plug (T819.4272) ALUMINUM
T819.4274	Air Valve Kit (T819.4274)
T819.4275	Housing (T819.4275) ALUMINIUM
T819.4276	Air Valve Cover (T819.4276) ALUMINUM
T819.4277	Screw (T819.4277) STAINLESS STEEL
T819.4278	Gasket (T819.4278) SANTOPRENE
T819.4279	Valve block (T819.4279) ALUMINIUM
T819.4280	O-Ring (T819.4280) BUNA
T819.4281	Block (T819.4281) ACETAL
T819.4282	Valve plate (T819.4282) STAINLESS STEEL
T819.4283	Gasket (T819.4283) BUNA
T819.4284	U-Cup (T819.4284) BUNA
T819.4285	Shaft (T819.4285) ACETAL
T819.4286	Bushing (T819.4286) ACETAL
T819.4287	Bushing (T819.4287) ACETAL
T819.4288	Shaft (T819.4288) STAINLESS STEEL
T819.4289	O-Ring (T819.4289) BUNA
T819.4290	Carriage (T819.4290) ACETAL
T819.4291	Bushing (T819.4291) ACETAL
T819.4294	Gasket (T819.4294) HDPE FOAM
T819.4295	Cover Air Valve (T819.4295) ALUMINIUM
T819.4296	Shaft (T819.4296) STAINLESS STEEL
T819.4297	Hex head flange bolt (T819.4297) ST. STL
T819.4299	Manifold Inlet (T819.4299) NPT ALUMINUM
T819.4301	Piston (T819.4301) ALUMINIUM
T819.4302	Piston (T819.4302) CARBON STEEL
T819.4304	O-Ring (T819.4304) PTFE
T819.4306	Muffler 3/4" (T819.4306) MNPT
T819.4307	Hex head flange bolt (T819.4307) SST
T819.4311	Piston (T819.4311) STAINLESS STEEL
T819.4312	Hex head flange bolt (T819.4312) ST.STL
T819.4314	Hex head bolt (T819.4314) STAINLESS ST.
T819.4315	Seat (T819.4315) STAINLESS STEEL
T819.4316	O-Ring (T819.4316) PTFE
T819.4318	Seat (T819.4318) HYTREL
T819.4319	Seat (T819.4319) SANTOPRENE
T819.4321	Seat (T819.4321) POLYPROPYLENE
T819.4322	Ball (T819.4322) PTFE
T819.4323	Ball (T819.4323) ACETAL
T819.4324	Ball (T819.4324) STAINLESS STEEL

PART NUMBER	DESCRIPTION
T819.4325	Ball (T819.4325) HYTREL
T819.4326	Ball (T819.4326) SANTOPRENE
T819.4328	Diaphragm (T819.4328) SANTOPRENE
T819.4329	Diaphragm (T819.4329) PTFE
T819.4330	Diaphragm (T819.4330) HYTREL
T819.4336	Air chamber (T819.4336) ALUMINUM
T819.4337	Shaft (T819.4337) STAINLESS STEEL
T819.4339	Manifold Inlet (T819.4339) ALUMINIUM
T819.4341	Piston (T819.4341) ALUMINIUM
T819.4342	Piston (T819.4342) CARBON STEEL
T819.4343	Hex head flange bolt (T819.4343) ST.STL
T819.4348	Piston (T819.4348) STAINLESS STEEL
T819.4349	Seat (T819.4349) STAINLESS STEEL
T819.4350	O-Ring (T819.4350) PTFE
T819.4351	Seat (T819.4351) HASTELLOY
T819.4352	Seat (T819.4352) HYTREL
T819.4353	Seat (T819.4353) SANTOPRENE
T819.4355	Seat (T819.4355) POLYPROPYLENE
T819.4356	Seat (T819.4356) PVDF
T819.4357	Ball (T819.4357) PTFE
T819.4359	Ball (T819.4359) STAINLESS STEEL
T819.4360	Ball (T819.4360) HYTREL
T819.4361	Ball (T819.4361) SANTOPRENE
T819.4363	Diaphragm (T819.4363) HYTREL
T819.4364	Diaphragm (T819.4364) PTFE
T819.4365	Diaphragm (T819.4365) SANTOPRENE
T819.4368	Air Valve Cover (T819.4368) ALUMINUM
T819.4369	Shaft (T819.4369) STAINLESS STEEL
T819.4370	Fluid Cover (T819.4370) ACETAL
T819.4373	Piston (T819.4373) ALUMINIUM
T819.4374	Piston (T819.4374) ACETAL
T819.4375	Hex head flange bolt (T819.4375) ST.STL
T819.4376	Muffler 3/4" (T819.4376)
T819.4377	Hex head flange bolt (T819.4377) ST.STL
T819.4378	Fluid Chamber (T819.4378) POLYPROPYLENE
T819.4379	Manifold Inlet (T819.4379)
T819.4380	Manifold Outlet (T819.4380) PP
T819.4381	Piston (T819.4381) POLYPROPYLENE
T819.4385	Piston (T819.4385) PVDF
T819.4386	Seat (T819.4386) STAINLESS STEEL
T819.4388	Seat (T819.4388) STAINLESS STEEL
T819.4389	Seat (T819.4389) HYTREL
T819.4392	Seat (T819.4392) POLYPROPYLENE
T819.4393	Seat (T819.4393) PVDF
T819.4394	Ball (T819.4394) PTFE
T819.4395	Ball (T819.4395) ACETAL
T819.4396	Ball (T819.4396) STAINLESS STEEL
T819.4397	Ball (T819.4397) STAINLESS STEEL
T819.4398	Ball (T819.4398) SANTOPRENE
T819.4401	Diaphragm (T819.4401) HYTREL
T819.4402	Diaphragm (T819.4402) PTFE
T819.4403	Diaphragm (T819.4403) SANTOPRENE
T819.4414	Diaphragm (T819.4414) SANTOPRENE
T819.4415	Ball (T819.4415) FKM/VITON
T819.4416	Diaphragm (T819.4416) FKM/VITON

PART NUMBER	DESCRIPTION
T819.4432	O-Ring (T819.4432) PTFE
T819.4440	Guide (T819.4440) ACETAL
T819.4441	Stop (T819.4441) ACETAL
T819.4442	Guide (T819.4442) STAINLESS STEEL
T819.4443	Stop (T819.4443) STAINLESS STEEL
T819.4444	Guide (T819.4444) POLYPROPYLENE
T819.4445	Stop (T819.4445) POLYPROPYLENE
T819.4446	Ball (T819.4446) PTFE
T819.4447	Ball (T819.4447) STAINLESS STEEL
T819.4448	Ball (T819.4448) HYTREL
T819.4449	Ball (T819.4449) SANTOPRENE
T819.4450	Ball (T819.4450) BUNA
T819.4452	Diaphragm (T819.4452) SANTOPRENE
T819.4453	Diaphragm (T819.4453) PTFE
T819.4454	Diaphragm (T819.4454) HYTREL
T819.4455	Diaphragm (T819.4455) BUNA
T819.4457	Fluid Cover (T819.4457) ALU
T819.4458	Manifold outlet NPT (T819.4458) ALUMINUM
T819.4459	Hex head bolt (T819.4459) STAINLESS ST
T819.4460	Hex nut (T819.4460) STAINLESS STEEL
T819.4461	Flat washer (T819.4461) STAINLESS STEEL
T819.4462	Base Feet (819.4462)
T819.4481	Piston (T819.4481) STAINLESS STEEL
T819.4482	Hex head flange bolt (T819.4482) ST.STL
T819.4483	Hex nut (T819.4483) STAINLESS STEEL
T819.4487	Fluid Cover (T819.4487) Polypropylene
T819.4490	Piston (T819.4490) POLYPROPYLENE
T819.4491	Hex head flange bolt (T819.4491) ST.STL
T819.4495	Piston (T819.4495) PVDF
T819.4497	Fluid Chamber (T819.4497) POLYPROPYLENE
T819.4498	Manifold Inlet (T819.4498) POLYPROPYLENE
T819.4499	Manifold Outlet (T819.4499) PP
T819.4500	Piston (T819.4500) POLYPROPYLENE
T819.4503	Manifold outlet (T819.4503) PVDF
T819.4504	Piston (T819.4504) PVDF
T819.4505	Seat (T819.4505) PVDF
T819.4509	Repair kit (T819.4509)
T819.4510	Repair kit (T819.4510)
T819.4511	Repair kit (T819.4511)
T819.4512	Repair kit (T819.4512)
T819.4549	Repair kit (T819.4549)
T819.4559	Repair kit (T819.4559)
T819.4625	Repair kit (T819.4625)
T819.4635	Repair kit (T819.4635)
T819.4673	Repair kit (T819.4673)
T819.4676	Repair kit (T819.4676)
T819.4688	Repair kit (T819.4688)
T819.4689	Repair kit (T819.4689)
T819.4703	Repair kit (T819.4703)
T819.4705	Repair kit (T819.4705)
T819.4708	Repair kit (T819.4708)
T819.4711	Repair kit (T819.4711)
T819.4713	Repair kit (T819.4713)
T819.4717	Repair kit (T819.4717)
T819.4723	Repair kit (T819.4723)

PART NUMBER	DESCRIPTION
T819.4724	Repair kit (T819.4724)
T819.4752	Repair kit (T819.4752)
T819.4754	Repair kit (T819.4754)
T819.4755	Repair kit (T819.4755)
T819.4756	Repair kit (T819.4756)
T819.4794	Repair kit (T819.4794)
T819.4880	Repair kit (T819.4880)
T819.4921	Repair kit (T819.4921)
T819.4933	Repair kit (T819.4933)
T819.4934	Repair kit (T819.4934)
T819.4948	Repair kit (T819.4948)
T819.4950	Repair kit (T819.4950)
T819.4953	Repair kit (T819.4953)
T819.4956	Repair kit (T819.4956)
T819.4968	Repair kit (T819.4968)
T819.4969	Repair kit (T819.4969)
T819.4997	Repair kit (T819.4997)
T819.4999	Repair Kit (T819.4999)
T819.5001	Repair kit (T819.5001)
T819.5002	Repair kit (T819.5002)
T819.5003	Repair kit (T819.5003)
T819.5010	Repair kit (T819.5010)
T819.5052	Repair kit (T819.5052)
T819.5053	Repair kit (T819.5053)
T819.5054	Repair kit (T819.5054)
T819.5059	Repair kit (T819.5059)
T819.5066	Repair kit (T819.5066)
T819.5076	Repair kit (T819.5076)
T819.5080	Repair kit (T819.5080)
T819.5100	Repair kit (T819.5100)
T819.5101	Repair kit (T819.5101)
T819.5107	Repair kit (T819.5107)
T819.5121	Repair kit (T819.5121)
T819.5124	Repair kit (T819.5124)
T819.5128	Repair kit (T819.5128)
T819.5130	Repair kit (819.5130)
T819.5135	Repair kit (T819.5135)
T819.5148	Repair kit (T819.5148)
T819.5149	Repair kit (T819.5149)
T819.5162	Repair kit (T819.5162)
T819.5169	Repair kit (T819.5169)
T819.5172	Repair kit (T819.5172)
T819.5176	Repair kit (T819.5176)
T819.5183	Repair kit (T819.5183)
T819.5293	Repair kit (T819.5293)
T819.5341	Repair kit (819.5341)
T819.5700	Repair kit (T819.5700)
T819.5701	Repair kit (T819.5701)
T819.5702	Repair kit (T819.5702)
T819.5703	Repair kit (T819.5703)
T819.5704	Repair kit (T819.5704)
T819.5999	Shaft (T819.5999) ALUMINIUM
T819.6028	Repair kit (819.6028)
T819.6032	Repair kit VA08 (T819.6032)
T819.6033	Repair kit (819.6033)

PART NUMBER	DESCRIPTION
T819.6034	Repair kit VA08 (T819.6034)
T819.6048	Manifold Inlet (T819.6048) ALUMINUM
T819.6049	Manifold outlet (T819.6049) ALUMINUM
T819.6148	Diaphragm Kit (T819.6148)
T819.6149	Repair kit (T819.6149)
T819.6150	Repair kit (T819.6150)
T819.6177	Repair kit (T819.6177)
T819.6192	Repair kit (T819.6192)
T819.6195	Repair kit (T819.6195)
T819.6242	Repair kit (T819.6242)
T819.6245	Repair kit (T819.6245)
T819.6249	Air valve kit (T819.6249)
T819.6256	Gasket (T819.6256) BUNA
T819.6257	Gasket (T819.6257) BUNA
T819.6258	PIN (T819.6258) ACETAL
T819.6259	O-Ring (T819.6259) BUNA
T819.6261	Piston (T819.6261) ACETAL
T819.6262	O-Ring (T819.6262) FEP/VITON
T819.6267	O-Ring (T819.6267) FEP/VITON
T819.6269	Check Valve PVDF (T819.6269)
T819.6270	Diaphragm (T819.6270) PTFE
T819.6271	Plate (819.6271) Polypropylene
T819.6273	O-Ring (T819.6273) FKM/VITON
T819.6275	Piston PVDF (T819.6275)
T819.6277	O-Ring (T819.6277) FKM/VITON
T819.6280	Diaphragm kit (T819.6280)
T819.6281	Repair kit (T819.6281)
T819.6282	Repair kit (T819.6282)
T819.6283	Ball Kit (819.6283)
T819.6289	Repair kit (T819.6289)
T819.6295	Repair kit (T819.6295)
T819.6299	Repair kit (T819.6299)
T819.6300	Repair kit (T819.6300)
T819.6301	Repair kit (T819.6301)
T819.6307	Repair kit (T819.6307)
T819.6343	Seat (T819.6343) ACETAL
T819.6344	O-Ring (T819.6344) PTFE
T819.6349	Shaft kit (819.6349)
T819.6350	Bushing (T819.6350) ACETAL
T819.6351	Muffler 3/8" (T819.6351)
T819.6352	O-Ring (T819.6352) FKM/VITON
T819.6353	Shaft (T819.6353) STAINLESS STEEL
T819.6532	Repair kit (T819.6532)
T819.6556	Hex head bolt (T819.6556) STAINLESS ST
T819.6557	O-Ring (T819.6557) PTFE
T819.6565	Air Valve Kit (T819.6565)
T819.6566	Hex head flangebolt (T819.6566) ST. STL
T819.6567	Air Cover (T819.6567) ALUMINUM
T819.6568	Housing (T819.6568) ALUMINUM *OBSOLETE*
T819.6569	Air Valve Cover (T819.6569) ALUMINUM
T819.6571	Shaft (T819.6571) ACETAL
T819.6572	Bushing (T819.6572) ACETAL
T819.6573	U-Cup (T819.6573) BUNA
T819.6574	Gasket (T819.6574) HDPE FOAM
T819.6575	Valve plate (T819.6575) STAINLESS STEEL

PART NUMBER	DESCRIPTION
T819.6576	Gasket (T819.6576) BUNA
T819.6577	Bushing (T819.6577) ACETAL
T819.6578	Shaft (T819.6578) STAINLESS STEEL
T819.6579	U-Cup (T819.6579) BUNA
T819.6580	PIN (T819.6580) ACETAL
T819.6581	PIN (T819.6581) STAINLESS STEEL
T819.6582	O-Ring (T819.6582) BUNA
T819.6584	O-Ring (T819.6584) BUNA
T819.6585	Liquid chamber (T819.6585) ALUMINUM
T819.6586	Piston (T819.6586) ALUMINIUM
T819.6587	Hex Screw Flange (T819.6587) SST
T819.6588	Piston (T819.6588) ALUMINIUM
T819.6589	Foot (T819.6589) CARBON STEEL
T819.6591	Muffler 1" (T819.6591) MNPT
T819.6592	Seat (T819.6592) STAINLESS STEEL
T819.6593	O-Ring (T819.6593) PTFE
T819.6594	Seat (T819.6594) HYTREL
T819.6595	Seat (T819.6595) SANTOPRENE
T819.6596	Ball (T819.6596) PTFE
T819.6597	Ball (T819.6597) ACETAL
T819.6598	Ball (T819.6598) SANTOPRENE
T819.6600	Diaphragm (T819.6600) PTFE
T819.6601	Diaphragm (T819.6601) SANTOPRENE
T819.6602	Diaphragm (T819.6602) HYTREL
T819.6784	Repair kit (T819.6784)
T819.6860	U-Cup (T819.6860)
T819.6861	Muffler (T819.6861)
T819.6863	Cup (T819.6863) Valve
T819.6864	Repair kit (T819.6864)
T819.6865	Ball (T819.6865) HYTREL
T819.6866	Seat (T819.6866) SANTOPRENE
T819.6867	O-Ring (T819.6867) FEP/VITON
T819.6868	Valve block (T819.6868) ALUMINIUM
T819.6869	O-Ring (T819.6869) BUNA
T819.6871	Hex head flange bolt (T819.6871)ST STEEL
T819.6872	Flat washer (T819.6872) STAINLESS STEEL
T819.6873	O-Ring (T819.6873) PTFE
T819.6874	Repair kit (T819.6874)
T819.6876	Repair kit (T819.6876)
T819.6882	Piston (T819.6882) ALUMINIUM
T819.6882	Shim (T819.6882)
T819.6898	Air Valve Kit (T819.6898)
T819.6901	Valve block (T819.6901)
T819.6902	Shaft (T819.6902) STAINLESS STEEL
T819.6904	Gasket (T819.6904) BUNA
T819.6905	Plate (T819.6905) STAINLESS STEEL
T819.6909	O-Ring (T819.6909) FKM/VITON
T819.6910	U-Cup (T819.6910) FKM/VITON
T819.6911	Piston (T819.6911) STAINLESS STEEL
T819.6912	Shaft (T819.6912) ALUMINIUM
T819.6913	Carriage (T819.6913) ACETAL
T819.6914	Shaft (T819.6914) ACETAL
T819.6915	Air valve cover (T819.6915) PP
T819.6916	Center block (T819.6916) Polypropylene
T819.6917	Gasket (T819.6917) BUNA

PART NUMBER	DESCRIPTION
T819.6919	Valve plate (T819.6919) STAINLESS STEEL
T819.6920	Shaft (T819.6920) CARBON STEEL
T819.6925	Guide (T819.6925) PVDF
T819.6926	Stop (T819.6926) PVDF
T819.6927	Spacer (T819.6927)
T819.6928	Duckbill (T819.6928) BUNA
T819.6929	Fluid Cover (T819.6929) ACETAL
T819.6931	Manifold inlet (T819.6931) BSPT Acetal
T819.6936	Self-tapping pan headscrew(T819.6936) ST
T819.6937	Hex flange nut (T819.6937) SST
T819.6938	Air Chamber Right (T819.6938) PP
T819.6939	Air Chamber Left (T819.6939) PP
T819.6942	Plug (T819.6942) ACETAL
T819.6944	O-Ring (T819.6944) FEP/VITON
T819.6945	Fluid Cover (T819.6945) PP
T819.6947	Manifold inlet (T819.6947) BSPT PP
T819.6949	Manifold (T819.6949) POLYPROPYLENE
T819.6956	Manifold inlet (T819.6956) BSPT PVDF
T819.6958	Manifold outlet (819.6958) BSPT PVDF
T819.6961	Piston (T819.6961) PVDF
T819.6968	Piston (T819.6968) STAINLESS STEEL
T819.6969	Air Chamber (T819.6969) Polypropylene
T819.6978	Manifold Inlet (T819.6978) ALUMINUM
T819.6979	Manifold Inlet (T819.6979) BSPT ALU
T819.6980	Manifold Inlet (T819.6980) ALUMINIUM
T819.6981	Manifold (T819.6981) POLYPROPYLENE
T819.6984	Manifold Outlet (T819.6984) ALUMINUM
T819.6986	Manifold (T819.6986) POLYPROPYLENE
T819.7000	Muffler 3/4" (T819.7000) MNPT
T819.7012	Manifold inlet (T819.7012) SST BSP
T819.7013	Manifold outlet (T819.7013) SST
T819.7014	Hex nut (T819.7014) STAINLESS STEEL
T819.7015	Liquid chamber (T819.7015) SST
T819.7016	Gasket (T819.7016) BUNA
T819.7018	O-Ring (T819.7018) POLYURETHANE
T819.7027	Valve Check (T819.7027) ACETAL
T819.7028	Check Valve Polypropylene (T819.7028)
T819.7029	Check Valve PVDF (T819.7029)
T819.7048	Manifold outlet (T819.7048) SST NPT
T819.7049	Manifold inlet (T819.7049) SST NPT
T819.7051	Hex head flange bolt (T819.7051) ST. STL
T819.7052	Hex head flange bolt (T819.7052)
T819.7056	Ball (T819.7056) GEOLAST
T819.7057	Seat (T819.7057) GEOLAST
T819.7058	Diaphragm (T819.7058) GEOLAST
T819.7059	Ball (T819.7059) GEOLAST
T819.7060	Seat (T819.7060) GEOLAST
T819.7061	Diaphragm (T819.7061) GEOLAST
T819.7062	Ball (T819.7062) GEOLAST
T819.7063	Seat (T819.7063) GEOLAST
T819.7064	Diaphragm (T819.7064) GEOLAST
T819.7065	Ball (T819.7065) GEOLAST
T819.7066	Seat (T819.7066) GEOLAST
T819.7067	Diaphragm (T819.7067) GEOLAST
T819.7068	Connector (T819.7068) POLYPROPYLENE

PART NUMBER	DESCRIPTION
T819.7069	Diaphragm (T819.7069) SANTOPRENE
T819.7076	Fluid Cover (T819.7076) SST
T819.7098	Manifold inlet (T819.7098) SST NPT
T819.7099	Manifold Outlet (T819.7099) SST NPT
T819.7102	Housing, center (T819.7102) SST
T819.7103	Air Valve Cover (T819.7103) SST
T819.7104	Cover Air Valve (T819.7104) SST
T819.7110	Cover Air Valve (T819.7110) SST
T819.7114	Seat (T819.7114) FKM/VITON
T819.7115	Seat (T819.7115) FKM/VITON
T819.7116	Seat (T819.7116) BUNA
T819.7117	Seat (T819.7117) BUNA
T819.7118	Seat (T819.7118) BUNA
T819.7119	Diaphragm (T819.7119) BUNA
T819.7120	Diaphragm (T819.7120) BUNA
T819.7124	Ball (T819.7124) FKM/VITON
T819.7125	Ball (T819.7125) BUNA
T819.7126	Ball (T819.7126) FKM/VITON
T819.7127	Ball (T819.7127) BUNA
T819.7128	Ball (T819.7128) FKM/VITON
T819.7129	Ball (T819.7129) BUNA
T819.7130	Diaphragm (T819.7130) BUNA
T819.7131	Diaphragm (T819.7131) FKM/VITON
T819.7132	Diaphragm (T819.7132) FKM/VITON
T819.7133	Diaphragm (T819.7133) FKM/VITON
T819.7134	Seat (T819.7134) FKM/VITON
T819.7155	Manifold NPT (T819.7155) Polypropylene
T819.7156	Manifold (T819.7156) POLYPROPYLENE
T819.7158	Plug (T819.7158) ACETAL
T819.8001	Diaphragm (T819.8001) SANTOPRENE
T819.8002	Diaphragm (T819.8002) HYTREL
T819.8067	Diaphragm (T819.8067) GEOLAST
T819.9740	Air Valve Kit (T819.9740)
T819.9746	Pin (T819.9746)
T819.9752	Hex head flange bolt (T819.9752) SST
T819.9753	Hex head bol (T819.9753) STAINLESS STEEL
T819.9758	Washer Outlet (T819.9758)
T819.9759	Washer (T819.9759) Inlet
T819.9760	Bearing (T819.9760)
T819.9761	Pilot valve assembly kit (T819.9761)
T819.VA25	U-Cup (T819.VA25) BUNA
T859.0000	Center section rebuild kit (T859.0000)
T859.0001	Repair kit (T859.0001)
T859.0002	Repair kit (T859.0002)
T859.0003	Repair kit (T859.0003)
T859.0004	Repair kit (T859.0004)
T859.0005	Repair kit (859.0005)
T859.0006	Repair kit (T859.0006)
T859.0007	Repair kit (T859.0007)
T859.0008	Repair kit (T859.0008)
T859.0009	Seat Kit (T859.0009) ACETAL
T859.0010	Seat Kit (T859.0010) ALUMINUM
T859.0011	Seat Kit (T859.0011) BUNA
T859.0012	Seat Kit (T859.0012) GEOLAST
T859.0013	Seat Kit (T859.0013) HYTREL

PART NUMBER	DESCRIPTION
T859.0014	Seat Kit (T859.0014) POLYPROPYLENE
T859.0015	Seat Kit (T859.0015) SANTOPRENE
T859.0016	Seat Kit (T859.0016) STAINLESS STEEL
T859.0017	Seat Kit (T859.0017) FKM/VITON
T859.0018	Ball Kit (T859.0018) ACETAL
T859.0019	Check ball kit (T859.0019)
T859.0020	Check ball kit (T859.0020)
T859.0021	Check ball kit (T859.0021)
T859.0022	Check ball kit (T859.0022)
T859.0023	Check ball kit (T859.0023)
T859.0024	Check ball kit (T859.0024)
T859.0025	Check ball kit (T859.0025)
T859.0026	Check ball kit (T859.0026)
T859.0027	Check ball kit (T859.0027)
T859.0028	Manifold Out NPT (T859.0028) ALUMINUM
T859.0029	Manifold Outlet (T859.0029) ALUMINUM BSP
T859.0030	Manifold Inlet (T859.0030) ALUMINUM
T859.0031	Manifold Inlet (T859.0031) ALUMINUM BSP
T859.0032	Fluid Cover (T859.0032) ALUMINUM
T859.0032	Fluid Cover (T859.0032) Kit
T859.0033	Bolt Kit (T859.0033)
T859.0034	O-Ring Kit (T859.0034) PTFE
T859.0035	Center Shaft Kit (T859.0035)
T859.0036	Pilot valve assembly kit (T859.0036)
T859.0037	Bushing Kit (T859.0037)
T859.0038	Air Valve (T859.0038)
T859.0039	Air kit (T859.0039)
T859.0040	Air Valve Kit (T859.0040)
T859.0041	Air Valve kit (T859.0041)
T859.0044	Air valve assembly (T859.0044)
T859.0051	Pulse Count Kit (T859.0051)
T859.0052	Pulse Count Kit (T859.0052)
T859.0055	Piston kit (T859.0055)
T859.0056	Repair kit (T859.0056)
T859.0058	Center Flange (T859.0058) POLYPROPYLENE
T859.0061	End Flange (T859.0061) POLYPROPYLENE
T859.0064	Center Flange (T859.0064) POLYPROPYLENE
T859.0067	End Flange (T859.0067) POLYPROPYLENE
T859.0070	Fluid Cover (T859.0070)
T859.0071	Fluid Cover (T859.0071) Kit
T859.0075	Bolt kit (T859.0075)
T859.0081	Fluid Cover (T859.0081) Kit
T859.0082	Piston kit (T859.0082)
T859.0085	Screw kit (T859.0085)
T859.0087	Seat Kit (T859.0087) PVDF
T859.0103	Air Valve End Cap Kit (T859.0103)
T859.0108	Repair Kit (T859.0108)
T859.0116	Pilot valve assy (T859.0116)
T859.0131	Repair Kit (T859.0131)
T859.0132	Repair Kit (859.0132)
T859.0132	Repair Kit (T859.0132)
T859.0133	Repair Kit (T859.0133)
T859.0134	Repair Kit (T859.0134)
T859.0136	Repair Kit (T859.0136) VA25
T859.0137	Repair Kit (T859.0137) VA25

PART NUMBER	DESCRIPTION
T859.0138	Repair Kit (T859.0138)
T859.0139	Repair Kit (T859.0139) VA25
T859.0140	Repair Kit (T859.0140) VA25
T859.0142	Repair Kit (T859.0142) VA25
T859.0143	Repair Kit (T859.0143)
T859.0150	Air Valve Seal kit (T859.0150)
T859.0151	Air Valve Seal kit (T859.0151)
T859.0152	Center Shaft Kit (T859.0152)
T859.0154	Center Bushing Kit (T859.0154)
T859.0155	Air Valve Kit (T859.0155)
T859.0157	Air valve repair kit (T859.0157)
T859.0159	Center Rebuild Kit (T859.0159)
T859.0160	Rebuild Kit (T859.0160)
T859.0167	Air Cover Kit (T859.0167)
T859.0169	Air Cover Center Bolt Kit (T859.0169)
T859.0179	Seal kit (T859.0179)
T859.0181	Seal kit (T859.0181)
T859.0185	Outlet manifold elbow kit (T859.0185)
T859.0197	Diaphragm kit Buna (T859.0197)
T859.0198	Diaphragm kit Neo overmolded (T859.0198)
T859.0199	Diaphragm kit TF overmolded (T859.0199)
T859.0200	Diaphragm kit Geolast (T859.0200)
T859.0201	Diaphragm kit TPE (T859.0201)
T859.0202	Repair kit (T859.0202)
T859.0203	Diaphragm kit FKM/Viton (T859.0203)
T859.0204	Diaphragm kit Neoprene (T859.0204)
T859.0205	Diaphragm kit PTFE (T859.0205)
T859.0207	Fluid Plate Kit (T859.0207)
T859.0208	Repair Kit (T859.0208)
T859.0209	O-Ring kit Buna (T859.0209)
T859.0210	O-Ring kit FKM (T859.0210)
T859.0211	O-Ring kit PTFE (T859.0211)
T859.0212	Seat Kit Acetal (T859.0212)
T859.0213	Seat Kit Aluminum (T859.0213)
T859.0214	Seat kit Buna (T859.0214)
T859.0215	Seat kit Geolast (T859.0215)
T859.0216	Seat kit TPE (T859.0216)
T859.0217	Seat Kit Polypropylene (T859.0217)
T859.0218	Seat Kit Santoprene (T859.0218)
T859.0219	Seat kit Stainless Steel (T859.0219)
T859.0220	Seat kit FKM/Viton (T859.0220)
T859.0221	Ball Kit Acetal (T859.0221)
T859.0222	Ball Kit Buna (T859.0222)
T859.0223	Ball kit Geolast (T859.0223)
T859.0224	Ball Kit TPE (T859.0224)
T859.0225	Ball Kit Neoprene (T859.0225)
T859.0226	Ball Kit Neoprene Weighted (T859.0226)
T859.0227	Ball Kit PTFE (T859.0227)
T859.0228	Ball Kit Santoprene (T859.0228)
T859.0229	Ball kit Viton (T859.0229)
T859.0235	Piston kit (T859.0235)
T859.0238	Muffler 3/4 npt (T859.0238)
T859.0252	Muffler kit (T859.0252)
T859.0266	Center section rebuild kit (T859.0266)
T859.0268	Center shaft kit (T859.0268)

PART NUMBER	DESCRIPTION
T859.0270	Center Bushing Kit (T859.0270)
T859.0275	O-Ring kit PTFE (T859.0275)
T859.0280	Diaphragm kit PTFE Overmold (T859.0280)
T859.0281	Diaphragm kit Santoprene (T859.0281)
T859.0282	Diaphragm kit FKM (T859.0282)
T859.0283	Diaphragm kit PTFE (T859.0283)
T859.0286	Seat kit (T859.0286) PVDF
T859.0287	Seat kit Polypropylene (T859.0287)
T859.0288	Seat kit Santoprene (T859.0288)
T859.0289	Seat kit (T859.0289) STAINLESS STEEL
T859.0290	Ball kit (T859.0290) PTFE
T859.0291	Ball kit (T859.0291) SANTOPRENE
T859.0292	Ball kit (T859.0292) FKM/VITON
T859.0293	Piston inner (T859.0293) ALUMINIUM
T859.0300	Diaphragm kit PTFE Bonded (T859.0300)
T859.0314	Center rebuild kit (T859.0314)
T859.0316	Center shaft kit (T859.0316)
T859.0318	Fluid Cover (T859.0318) Polypropylene
T859.0320	O-Ring Kit (T859.0320) PTFE
T859.0322	Manifold (T859.0322) POLYPROPYLENE
T859.0323	Manifold Inlet (T859.0323) POLYPROPYLENE
T859.0324	Fluid Cover (T859.0324) PVDF
T859.0326	Repair kit (T859.0326)
T859.0328	Diaphragm kit PTFE (T859.0328)
T859.0331	Seat kit (T859.0331) PVDF
T859.0332	Seat kit (T859.0332) POLYPROPYLENE
T859.0333	Seat kit (T859.0333) SANTOPRENE
T859.0334	Seat kit (T859.0334) STAINLESS STEEL
T859.0335	Ball kit (T859.0335) PTFE
T859.0336	Ball kit (T859.0336) SANTOPRENE
T859.0337	Ball kit (T859.0337) FKM/VITON
T859.0339	Manifold (T859.0339) POLYPROPYLENE
T859.0340	Manifold (T859.0340) POLYPROPYLENE
T859.0341	Manifold Outlet (T859.0341) PVDF
T859.0342	Manifold Inlet (T859.0342) PVDF
T859.0434	Repair kit (T859.0434)
T859.0435	Repair kit (T859.0435)
T859.0443	Repair kit (T859.0443)
T859.0444	Repair kit (T859.0444)
T859.0662	Seat Kit (T859.0662) PVDF
T859.0677	Repair kit (T859.0677)